



the quality, value product range

VARILIGHT®
VALUE



XS6B



XS5W



XS5U2W

Ordering is
SIMPLE and EASY
*For Matt Chrome
Accessories with Black
Inserts add B and for
White add W

B = Black inserts
W = White Inserts

Cat No. _____

Toggle Switches

Polar White	Matt Chrome with Black or White inserts	Matt Chrome with Decorative inserts	
		XST1	1-Gang 10A 1 or 2-Way Toggle Switch
		XST2	2-Gang 10A 1 or 2-Way Toggle Switch
		XST3	3-Gang 10A 1 or 2-Way Toggle Switch
		XST7	1-Gang 10A Intermediate Toggle Switch
		XST71	2-Gang 10A Intermediate Switch + 10A 1 or 2-Way Toggle Switch
		XST77	2-Gang 10A Intermediate Toggle Switch
		XST9	4-Gang 10A 1 or 2-Way Toggle Switch (Twin Plate)

Impulse Push Switches - A brand new concept in decorative wiring accessories

		XSP1	1-Gang 6A 1 or 2-Way Push-On/Off Impulse Switch
		XSP2	2-Gang 6A 1 or 2-Way Push-On/Off Impulse Switch
		XSP3	3-Gang 6A 1 or 2-Way Push-On/Off Impulse Switch (Twin Plate)
		XSP4	4-Gang 6A 1 or 2-Way Push-On/Off Impulse Switch (Twin Plate)

Momentary Push to Make Switches

		XSM1	1-Gang 6A 1-Way Push-to-Make Momentary Switch
		XSM2	2-Gang 6A 1-Way Push-to-Make Momentary Switch
		XSM3	3-Gang 6A 1-Way Push-to-Make Momentary Switch (Twin Plate)
		XSM4	4-Gang 6A 1-Way Push-to-Make Momentary Switch (Twin Plate)

Sockets

XO4PW			1-Gang 13A Switched Socket (Single Pole)
XO4UW			1-Gang 13A Unswitched Socket
XO4W	XS4*	XS4D	1-Gang 13A Switched Socket
XO5PW			2-Gang 13A Switched Socket (Single Pole)
XO5UW			2-Gang 13A Unswitched Socket
XO5W	XS5*	XS5D	2-Gang 13A Switched Socket
	XS5UAC*		2-Gang 13A Single Pole Switched Socket + 1x USB A + 1x USB C Charging Ports
	XS5U2*		2-Gang 13A Unswitched Socket + 2x 5V DC 2100mA USB Charging Ports
XO5U2SW	XS5U2S*	XS5U2SD	2-Gang 13A Switched Socket + 2x 5V DC 2100mA USB Charging Ports
	XS5VS*		2-Gang 13A Single Pole Switched Socket V-Pro Smart Wi-Fi Supla

DataGrid Plate - (For TV, Telephone, Data Etc)

		XSG1	DataGrid Plate (1 Grid Space)
		XSG2	DataGrid Plate (2 Grid Spaces)
		XSG4	DataGrid Twin Plate (4 Grid Spaces)

Other Accessories

XO8W		XS8	1-Gang TV Socket, Co-Axial
		XS88	2-Gang TV Socket, Co-Axial
		XS88S	2-Gang TV Socket, Co-Axial + F-Type Satellite
	XS8ISO*		1-Gang TV Socket, Isolated Co-Axial
		XS8S	1-Gang TV Socket, F-Type Satellite
XO5B		XSSB	Single Blank Plate
XO5DB		XSDB	Double Blank Plate
XO6W	XS6*	XS6D	13A Switched Fused Spur
XO6NW	XS6N*	XS6ND	13A Switched Fused Spur + Neon
XO6UW	XS6U*	XS6UD	13A Unswitched Fused Spur
	XS6FON*		13A Switched Fused Spur + Neon + Flex Outlet
	XS6UFO*	XS6UFOD	13A Unswitched Fused Spur + Flex Outlet
	XSFO*	XSFOFOD	13A Flex Outlet Plate
XO20NW	XS20N*	XS20ND	1-Gang 20A Double Pole Rocker Switch + Neon Indicator Light
XO20W	XS20*	XS20D	1-Gang 20A Double Pole Rocker Switch
XO45NW		XS45N	45A Cooker Switch + Neon (Vertical Twin Plate Red Rocker)
XO45PW	XS45P*		45A Cooker Panel with 13A Switched Socket Outlet (Red Rocker)
XO45SW		XS45S	45A Cooker Switch (Single Plate Red Rocker)
XO45O			45A Cooker Flex Output (Single Plate)
	XSRP2A*		1-Gang 2A Round Pin Socket
XORP5AW	XSRP5A*		1-Gang 5A Round Pin Socket
	XSRP15A*		1-Gang 15A Round Pin Socket
XOFIW	XSFI*		10A Fan Isolating Switch (3 Pole)
XOSSW	XSSS*		Dual Voltage Shaver Socket
XOTMW	XSTM*		1-Gang Telephone Master Socket 240V/115V
XOTSW	XSTS*		1-Gang Telephone Slave (Extension) Socket
	XSTVFM*		2-Gang Duplex Socket, TV/FM